

**D**

MTC - MEDION Technologie Center  
 D - 45467 Mülheim / Ruhr  
 Hotline: 01805 - 633 466 **BT**  
 Fax: 01805 - 654 654  
 (0,14 Euro/Minute innerhalb des deutschen Festnetzes)  
[www.medion.de/service](http://www.medion.de/service)

**CH**

MEDION Service Center  
 Rütistraße 28  
 CH - 8952 Schlieren  
 Hotline 0848 - 33 33 32  
[service-switzerland@medion.com](mailto:service-switzerland@medion.com)

**E**

MEDION Service Center Visonic S.A.  
 Alejandro Sanchez 95-97  
 E - 28019 Madrid  
 Hotline 90251448  
 Fax 914604772  
[service-spain@medion.com](mailto:service-spain@medion.com)

**I**

MEDION Service Center  
 Service on site S.P.A.  
 Via Kennedy 21  
 I - 20023 Cerro Maggiore (MI)  
 Hotline: 199 309077  
[service-italy@medion.com](mailto:service-italy@medion.com)

**NL**

MEDION Service Center  
 Antwoordnummer 4015  
 NL - 5980 ZX Panningen  
 Hotline: 0900 - 633 4660  
 Fax 0900 - 654 6540  
[www.medion.com/nl](http://www.medion.com/nl)

**BE**

MEDION Service Center  
 John F. Kennedylaan 16a  
 NL - 5981 XC Panningen  
 Hotline 022006198  
 Fax 022006199  
[www.medion.com/nl](http://www.medion.com/nl)

**AT**

MEDION Service Center  
 Franz-Fritsch-Str. 11  
 AT - 4600 Wels  
 Hotline: 0810 - 001048  
 Fax: 07242 - 93967592  
[www.medion.de/service](http://www.medion.de/service)

**F**

MEDION France  
 CS 90180  
 F - 72207 La Fleche Cedex  
 Indigo no. 0825 81 1000  
[pc-support-fr@medion.com](mailto:pc-support-fr@medion.com)

**UK**

MEDION Electronics Ltd.  
 120 Faraday Park, Faraday Road, Dorcan  
 UK - Swindon SN3 5JF, Wilts  
 Hotline 0870 7270370  
 Fax 01793 715716  
[www.medion.co.uk](http://www.medion.co.uk)

**DK**

Service Provider  
 Naverland 31  
 DK- 2600 Glostrup  
 Hotline: (+45) 70212024  
 Fax: (+45) 70212029  
[service-denmark@medion.com](mailto:service-denmark@medion.com)

# Wireless LAN INTERNET RADIO

**MD 85651**

**Schnellstartanleitung**  
**Quick Start Guide**  
**Instructions de démarrage rapide**  
**Guida rapida**  
**Manual de inicio rápido**  
**Snelstarthandleiding**  
**Lynstartvejledning**



**MEDION**<sup>®</sup>

# Wireless LAN INTERNET RADIO



**MD 85651**

## **INSTRUCTION MANUAL**

# TABLE OF CONTENTS

SAFETY INSTRUCTIONS .....	2
PREPARATION .....	4
Unpacking the device .....	4
Inserting the batteries into the remote control .....	4
Connections .....	4
OVERVIEW .....	5
W-LAN Radio .....	5
Remote Control .....	6
MENÜSTRUKTUR .....	9
INSTALLATION .....	11
Network Setup .....	11
Configuration as a Wireless Client .....	12
Configuration as a Wired Client .....	14
Configuration as a Wireless Access Point (AP) .....	16
Using the IP Radio as a Media Client .....	18
LISTENING TO MUSIC .....	19
Listening to Internet Radio .....	19
Listening to FM Radio .....	21
Listening to the music in your computer .....	23
Listening to the Music on your USB drive .....	25
The Playback Screen .....	26
ALARM .....	27
Clock .....	27
Alarm settings .....	28
Snooze .....	30
MISCELLANEOUS SETUP FUNCTIONS .....	31
Backlight Settings .....	31
Language Choice .....	31
Equalizer Settings .....	31
Reset to Factory Default Settings .....	32
Clear Favorites .....	32
Check Firmware Version .....	32
Software Update .....	32
APPENDIX .....	33
Care and Maintenance .....	33
Problems .....	33
TECHNICAL DATA .....	35
DISPOSAL .....	36
RESTRICTED WARRANTY .....	37

# SAFETY INSTRUCTIONS



## About these instructions

Please read these instructions carefully before using the device. Note the warnings on the device and in the operating instructions

Always keep the operating instructions close to hand. If you sell or give the unit away, please ensure that you also pass on these instructions.

## Keep electrical equipment out of reach of children

---

Children can be injured by electrical devices. Never allow children to use electrical appliances unattended. Keep plastic packaging out of the reach of children. There is a risk of suffocation.

## Setting the appliance up safely

---

Place the device on a sturdy, level surface. It is not designed for use in rooms that are very humid (e.g. bathrooms). Please observe the following installation conditions:

- Ensure that ventilation is adequate. The ventilation unit should not be obstructed by placing objects such as newspapers, table cloths, curtains, etc. on the vents.
- Do not place the device near heat sources (e.g. heaters) that could affect the unit.
- Do not place the unit in direct sunlight.
- Avoid contact with water droplets or spray and do not place vases or anything containing water on the unit.
- Never set up the appliance near magnet fields. (e.g. television sets or speakers).
- Naked flames, such as lit candles, must not be placed on or near the device.

## Power connection

---

Only connect the appliance to a power socket (230 V ~ 50 Hz) that is easy to reach and is close to the place where you have set up the appliance. The power socket must be freely accessible so that you can unplug the appliance quickly, if necessary.

Do not use the device if the mains plug, cable or device itself has been dropped. If the plug, cable or appliance is damaged, immediately remove the plug from the power supply.

Ensure the mains cable is out of harms way and will not trip people up. There should be no kinks or folds in the power cable.

Do not connect the device immediately to the mains if the unit has been moved from a cold to a warm room. Any condensation which forms could damage the unit. The device can be operated as soon as the unit has reached room temperature.

## Thunder storms

Unplug the device if you are away for a long period of time or there is a storm.

## Never undertake your own repairs

---



Never try to open and/or repair the device yourself. There is a risk of electric shock! Do not interfere with the unit's power cable.

If there is a fault contact our Service Centre or other suitable specialist workshop.

## Headphones

---

Listening to the unit at a high volume with headphones or ear phones can damage your hearing.

Lower the volume before putting on head/earphones. Your hearing can be damaged if you listen at high volumes over a long period or if the volume is increased too suddenly.

## Safe handling of batteries

---

The remote control is battery operated. Please note the following:

- Keep the batteries out of reach of children. They can be fatal if swallowed. If a battery is swallowed, please obtain immediate medical assistance.
- Do not throw batteries into a fire, do not short-circuit them and do not dismantle them.
- If necessary clean the battery and device contacts before insertion.
- Always change all batteries at the same time.
- Only use batteries of the same type. Do not use different types of batteries; do not use a mix of used and new batteries.
- Please take note of the polarity (+/-) when inserting the batteries.
- Remove the batteries if the unit is not going to be used for long periods.
- Remove the empty batteries immediately from the unit! There is an increased risk of leakage.
- Do not expose batteries to extreme conditions; for example, do not place the unit on top of radiators. There is an increased risk of leakage.
- Never try to recharge non-rechargeable batteries. There is a risk of an explosion!
- Remove leaking batteries from the device immediately. Clean the contacts before inserting new batteries. There is a risk of skin irritations from battery acid!
- If battery acid leaks out it is essential to avoid contact with the skin, eyes and mucous membranes! If the acid does come into contact with skin, immediately rinse the affected areas with plenty of clear water and contact a doctor immediately.

# PREPARATION

## Unpacking the device

Remove all packaging materials including the film on the front of the unit..



**WARNING!**

Do not let children play with the plastic wrapping. There is a risk of suffocation!


### Package contents

- IP radio device
- WiFi antenna (2 dBi)
- FM antenna (cable with 2.5 mm plug)
- Power adapter (CD 5V/3A)
- Remote control
- 2 x batteries 1,5 V (size AAA/R03)
- CD-ROM with the Media Server application *Twonky Vision* and the user manual
- Quick Start Guide


## Inserting the batteries into the remote control

Insert two 1.5 V batteries (AAA size) in the supplied remote control. Observe the polarity (+/-) as shown in the illustration: the negative end is placed next to the springs

Close the battery compartment before using the remote control.



## Connections



Back of the device




Before connecting any devices, switch off the IP Radio (ON/OFF switch (5) at the back of the device).

- W-LAN-mode operation or Access Point-Mode:** Schrauben Sie die mitgelieferte WiFi-Antenne in die Buchse LAN auf der Rückseite des Geräts (1).
- Betrieb im LAN-Modus:** Schließen Sie ein Ethernet-Kabel an den RJ 45-Port an (3).
- Betrieb des UKW-Radios:** Stecken Sie die mitgelieferte UKW-Antenne in die Buchse FM-ANT (2).
- Netzadapter:** Verbinden Sie den Gerätestecker des mitgelieferten Netzadapters mit dem Anschluss POWER und den Netzstecker mit einer Steckdose 230 V ~ 50 Hz.


# OVERVIEW

## W-LAN Radio




### Front

- 1. WiFi antenna (if connected)
- 2. Display
- 3. Infrared sensor for the remote control
- 4. USB port
- 5. Speaker



### Buttons on the top


- 6. STOP/ALARM:  
Open main menu / stop playback / switch off the alarm
- 7. POWER / LIGHT:  
press briefly: switch background light on and off;  
press and hold: switch device to standby mode
- 8. Arrow buttons
  - ◀: back to the previous selection
  - ▶: to the next selection
  - ▲: during playback: volume up /  
in a menu: selection upwards
  - ▼: during playback: volume down /  
in a menu: selection downward
- 9. OK: confirm selection
- 10. SNOOZE: in the alarm mode: repeat alarm after 10 minutes /  
during playback: set the switch off timer



### Rear

- 11. ON/OFF: switch on/off
- 12. POWER: socket for DC adapter
- 13. RESET: press the area with a pointed object in order to reset the device
- 14. FM ANT.: socket for FM antenna
- 15. Socket for headphone (3.5 mm)
- 16. LINE OUT: audio out for the connection to an external audio device (such as a stereo system or loudspeakers)
- 17. STATUS: status LED (flashes when no cable is connected; lights up permanently when an Ethernet cable is connected)
- 18. Socket for Ethernet cable (RJ45)
- 19. Socket for W-LAN antenna

# Remote Control



- A** **POWER:**  
switch device into standby mode and on again
- B** **Numeric buttons;** to enter numbers and charactes, press repeatedly until the desired character appears.
- C** **SNOOZE:**  
during alarm mode: repeat alarm every 10 minutes;  
during playback: set switch off timer
- D** **FM RADIO:** select FM radio operation
- E** **Arrow buttons:**  
◀: back to the previous selection  
▶: to the next selection  
▲: during playback: volume up /  
in a menu: selection downward  
▼: during playback: volume down /  
in a menu: selection downward;  
OK: confirm selection
- F** **MP3 READER:** Select device connected to the USB port
- G** **mute:**  
VOL-: volume down; VOL+: volume up
- H** **FWB:** during playback of audio titles:  
fast forward
- I** **Next:** select next radio station or title
- J** **Repeat:** during playback of audio titles:  
repeat function
- K** **Shuffle:** during playback of audio titles:  
shuffle function (random playback)
- L** **Favorite:** select radio station for the list of *Favorites*
- M** **Play/Pause:** during playback of audio titles:  
start and interrupt playback
- N** **Previous:** select previous station or title
- O** **REW:** during playback of audio titles:  
fast backward
- P** **MEDIA PLAYER:** select Media Player operation
- Q** **RADIO IP:** select IP Radio operation
- R** **STOP:** open main menu;  
during playback of audio titles: stop playback
- S** **Light:** switch display light on and off



## Function of the remote control in detail

### A) For the Selection Screen & Playback screen

		Select Screen (Screen with menu list)	Playback Screen (Screen with name of station / song)
SNOOZE		No function	Launches the timer for 15, 30, 45, or 60 min (stops the current music source after time selected) - Information screen displayed for 3s. - Goes back to standby screen with timer icon ON.
STOP		STOP MUSIC. Go back to main menu.	Identical.
POWER		Put the device in Standby mode.	Identical.
OK		Select the function.	Goes to option screen.
UP		Move to previous item.	Volume up. After 2s goes back to playback screen.
DOWN		Move to next item.	Volume down. After 2s goes back to playback screen.
LEFT	Radio IP	Goes back to the previous menu.	Goes back to radio list.
	Radio FM		If radio FM (direct access) : Goes back to the menu list. Otherwise: Goes back to radio list.
	Media Server		Goes back to the song list.
	MP3 Player		Goes back to song list.
RIGHT	Radio IP	Goes back to the next menu.	Goes back to radio list.
	Radio FM		If radio FM (direct access) : Goes back to the menu list. Otherwise: Goes back to radio list.
	Media Server		Goes back to the song list.
	MP3 Player		Goes back to song list.






### (B) For the Idle screen (clock screen)


	Standby screen & Music Playing	Standby Screen & Alarm Music	Standby Screen & No Music
SNOOZE	Launches 15, 30, 45, or 60 min timer to stop current music source (Goes back to clock screen with timer icon ON).	STOPS the music (Goes back to clock screen & reactivates alarm after 10 min.).	No function

STOP		STOPS MUSIC and goes back to main menu.	STOPS the music & Goes back to standby screen (No reactivation of alarm).	Alarm menu displayed.
POWER		Put the device in Standby mode.	Identical.	Identical.
OK		Displays playback screen.	Identical.	Main menu displayed.
UP		Volume up (after 2s goes back to playback screen).	Identical.	Main menu displayed.
DOWN		Volume down (after 2s goes back to playback Screen).	Identical.	Main menu displayed.
LEFT	Radio IP	First press: Goes back to Station radio screen. Second press: Goes back to radio list.	Identical.	Main menu displayed.
	Radio FM	First press: Goes back to Station radio screen. Second press: If radio FM (direct access) : Goes back to the menu list. Otherwise: Goes back to radio list	Goes back to radio list.	
	Media Server	First press: Goes back to song playing screenn.	Identical	
	MP3 Player	Second press: Goes back to songs list.		
RIGHT	Radio IP	Goes back to Station radio screen.	Identical.	Main menu displayed.
	Radio FM	First press: Goes back to Station radio screen. Second press: If radio FM (direct access) : Goes back to the menu list. Otherwise: Goes back to radio list.	Goes back to radio list.	
	Media Server	First press: Goes back to song playing screenn.	Identical.	
	MP3 Player	Second press: Goes back to songs list.		

# MENÜSTRUKTUR

Das Radio hat folgende Menüstruktur:

	<b>Internet Radio</b>	Station List	Location
			Genres
			New Stations
			Popular Stations
		Favorite Stations	All
			Genre
Location			
	<b>FM Radio</b>	FM Sensitivity	High
			Low
		Station List	
		Favorite Stations	
		Update List	
Direct Access			
	<b>Media Server</b>		
	<b>MP 3 Player</b>		
	<b>Alarm</b>	Alarm 1	OFF
			ON
		Alarm 2	OFF
			ON

	<b>Setup</b>	Clock	Current Time	
			Set Manually	
			Auto-Sync (NTP)	
		Language	Main Language	
			vTuner Language	
		Backlight	Always ON	
			1 Minute	
			3 Minutes	
			10 Minutes	
		Advanced Setup	30 Minutes	
			Equalizer	Normal
				Classic
				Rock
				Jazz
Pop				
Network Setup				
Configure Network				
Reset to Default				
Clear Favorites				
Device MAC Address				
Firmware Version				
F/W Upgrade (thru. USB).				

# INSTALLATION

## Network Setup

---

### Basic Requirements

For the Wi-Fi IP Radio device to work properly under your existing network environment, your network must feature the following:

You must have a router device with an enabled DHCP server function, so that it can automatically assign the IP address to your computer or another network device.

If you already have a router device in your home, it will be easy to setup the Wi-Fi IP Radio device with your existing network environment. If you don't know what you have on your home network, the following FAQ will help you to troubleshoot before operating your Wi-Fi IP Radio device.

**The minimum streams to receive Radio IP are :**

- 192 kB/s for a normal quality,
- 640 kB/s for an upper quality.

### How does your computer or Notebook PC access the Internet?

The answer might be one of the following:

#### Case I

I have to plug an Ethernet cable to the computer, and ...

... 1. I have to execute a dial-up program from my computer to link to the ISP service, and I can then access the Internet.

▶ You need to purchase a (wireless) broadband router.

... 2. No extra dial-up program is executed in my computer, but I set a fixed IP address in my computer.

... 3. No extra dial-up program is executed in my computer, and I set a dynamic IP address in my computer.

▶ There is a router device in your home. You can configure the Wi-Fi IP Radio device in wired client mode to operate it with your home network.

#### Case II

I use wireless connection, and ...

... 1. I have to execute a dial-up program from my computer to link to the ISP service, and I can then access the Internet.

▶ There is no router device in your home. You need to purchase a new router device to upgrade your home network.

... 2. No extra dial-up program is executed in my computer, but I set a fixed IP address in my computer.

▶ If the IP address is provided by your ISP supplier, there is probably no DHCP service in your home network. You need to buy a new router device.

▶ If the IP address is a virtual IP, such as 192.168.xxx.xxx, you should have a router device. Therefore, the Wi-Fi IP Radio device will function with your home network.

... 3. No extra dial-up program is executed in my computer, and I set the dynamic IP address in my computer.

▶ ... 3. There is a wireless router device in your home, the Wi-Fi IP Radio device will be able to operate with your home network.

Moreover, the Wi-Fi IP Radio allows to play the music loaded in your PC, this one being connected to the same router.

## Configuration as a Wireless Client








There are three network configuration modes available for the Wi-Fi IP Radio device: simple wireless client, wired client, or wireless access point (AP).





The factory default mode is the client mode. If an Ethernet cable is available, the device will automatically select a suitable client mode to operate. Users can also manually change the network configuration settings via the Setup menu "Setup/Advanced Setup/Configure Network".

If you have a 802.11b/g wireless network in your home, this mode is the most straightforward means of connecting the Wi-Fi IP Radio device to the existing network.






Simply power the device, without connecting an Ethernet cable, and the device will automatically switch to the wireless client mode and detect all available wireless APs (Access Points). The first time the device is set to the wireless client mode, you need to determine which AP to connect to and enter the encryption key. Once the settings have been established, the device will remember the settings and attempt to connect to the designated AP when it is switched on. However, if you encounter any difficulty in connecting to the designated AP, the device will display the AP list for you to configure the device once again.







### (A) Using the device for the first time, without an Ethernet cable connection:

	Screen on the right	Screen	Next screen	Comment
1				Initial screen
2				Device run as a Wireless Client.
3			"OK" button	Select the MMI language.
4			"OK" button	Select the Internet radio menu language.
5				Scanning for available APs.
6	"▼" button (once)		"▶" button or "OK" button	Select the AP that you can connect to your router device.
7	Numeric key pads		"OK" button	Enter the encryption key if the AP is encrypted.

8			"OK" button	Confirm the settings above.
9				Apply new settings.
10				The device is now in wireless client mode.
11				The device is already connected to your network.

**(B) Manually set to the Wireless Client Mode:**

	Screen on the right	Screen shot	Next screen	Comment
1			"OK" button	Initial screen
2	"▼" button (4 times)		"▶" button or "OK" button	
3	"▼" button (once)		"▶" button or "OK" button	
4			"▶" button or "OK" button	Manually select the wireless client mode.
5				Scanning for available APs.

6	"▼" button (once)		"▶" button or "OK" button	Select the AP that you can connect to your router device.
7	Numeric key pad		"OK" button	Enter the encryption key if the AP is encrypted.
8			"OK" button	Confirm the settings above.
9				Apply new settings.
10				The device is now in wireless client mode.
11				The device is already connected to your network.

## Configuration as a Wired Client

If there is no 802.11b/g wireless network in your home, and only a wired 802.3 network is available, the Wi-Fi IP Radio device can connect to the wired network via an Ethernet cable.





In this case, before powering the device, you need to plug the Ethernet cable into the RJ45 connector. The device will automatically switch to the wired client mode when it detects a link status via the Ethernet connection.

### (A) Using the device for the first time, without an Ethernet cable connection:






If the radio is switched on after a reset, wireless client mode will be chosen, even if Ethernet cable has already been plugged in.





	Screen on the right	Screen shot	Next screen	Comment
1				Initial screen



2				Device run as a Wired Client.
3			"▶" button or "OK" button	Select the MMI language.
4			"▶" button or "OK" button	Select the Internet radio menu language.
5				The device is now in wired client mode. It is already connected to your network.

#### (B) Manually set to the Wired Client Mode:

	Screen on the right	Screen	Next screen	Comment
1			"OK" button	Initial screen
2	"▼" button (4 times)		"▶" button or "OK" button	
3	"▼" button (once)		"▶" button or "OK" button	
4	"▼" button (once)		"▶" button or "OK" button	Manually select the wired client mode.
5	"▼" button (once)		"▶" button or "OK" button	Select the DHCP for auto configured IP address.




6			"OK" button	Confirm the settings above.
7				Apply new settings.
8				The device is now in wired client mode.
9				The device is already connected to your network











## Configuration as a Wireless Access Point (AP)

If you wish to extend your wireless network coverage range, you need to add new access points to specific locations in your home. This will enable other wireless notebook PCs and network devices to access the extended wireless network. The Wi-Fi IP Radio device can also be configured as a wireless AP. With this feature, you can easily extend your wireless coverage without having to purchase another AP.

To configure the Wi-Fi IP Radio device as an AP, you need to setup the device manually via the MMI menu "Setup/Advanced Setup/Configure Network/AP mode". You then need to enter the IP address, the SSID, the channel number and the AP encryption. Once these settings have been established, the device will automatically reboot and function as an AP.

### Manually set to the Wireless AP Mode:

	Screen on the right	Screen	Next screen	Comment
1			"OK" button	Initial screen
2	"▼" button (4 times)		"▶" button or "OK" button	
3	"▼" button (once)		"▶" button or "OK" button	

4	"▼" button (2 times)		"▶" button or "OK" button	Manually select the AP mode.
5	"▼" button (once)		"▶" button or "OK" button	Select the DHCP for auto configured IP address.
6	Numeric key pad		"OK" button	Enter the Identifier (name) for this AP.
7	Numeric key pad		"OK" button	Select the wireless channel to be allocated to this AP.
8	"▼" button (once)		"OK" button	Select one of the security functions.
9	Numeric key pad		"OK" button	Enter the encryption key if the AP is encrypted.
10			"OK" button	Confirm the settings above.
11				Apply new settings.
12				The device is in wireless AP mode now.
13				The device is already connected to your network and can now operate.

## Using the IP Radio as a Media Client

The IP Radio is compliant with the UPnP protocol, and the IP Radio works with any UPnP-based server software installed on your computer.

### Installing Twonky Vision

The supplied CD-ROM contains the Media Server Software *Twonky Vision*. Select the software for installation. In the first step, you select the language.

This selections applies both to the language for installation and for the installed software.


Follow the futher steps in the installation wizard.



### Connection between Wi-Fi IP Radio and Media Server

Establish the connection between the Wi-Fi IP Radio device and the media server.


On the Wi-Fi IP Radio device, select the "Media Server" function in the main menu (or press the "Media Player" hot key on the remote controller). The Wi-Fi IP Radio device will then initiate the server detection process. After a few seconds, it will detect a server and display "PC\_Hostname: Server Name"



This is the Media Server that you installed.

Press the 'OK' button to try to connect to the server.

The Wi-Fi IP Radio screen will read "Connecting...." and will then display the following list:



You can browse the "Music" list and play the music of your choice.

# LISTENING TO MUSIC

The Wi-Fi IP Radio device is a high-performance audio player that can play music from various types of source. You can use it to listen to Internet radios all over the world, local FM broadcasting services, music files in your computer, and even music files in portable MP3 players.


The following part of this manual explains how to listen to the music using the Wi-Fi IP Radio device.

## Listening to Internet Radio

Commands from the remote control:

⏪ ⏩	Go to preview/next station.
⏸ ▶	Back to station list.
Vol -, ▼	Decrease the hearing level.
Vol +, ▲	Increase the hearing level.
♥	Add (or cancel) the song from (to the) list of favourites.

To listen to music or programs on Internet radio stations, select the "Internet Radio" function in the main menu and then press the "OK" button to activate the Internet Radio function.



The first screen of the Internet Radio function displays a choice of 2 items:




"Station List": Retrieves the Internet radio station lists from the Internet server.

"Favorite Stations": Retrieves the favorite station lists stored in the device.

Press the "OK" button or the "▶" button to retrieve the Station List.

The device will then try to connect to the Internet radio server to retrieve the Internet radio stations. The following screen should be displayed:




It takes few seconds to get the list from the Internet. The next screen is as follows.



It means the Wi-Fi IP Radio has successfully connected to the Internet server and has retrieved information from the server.



However, if the following screen is displayed, it means that the device has encountered a problem in retrieving the list from the Internet server.



Please refer to the troubleshooting chapter to identify the problem and solve it step by step.


The following screen shots illustrate the sequence used to browse the radio station "FM PLUS" in France and play back music from it.

	Screen on the right	Screen shot	Next screen	Comment
1				Initial screen
2				
3	"▼" button (4 times)		"▶" button or "OK" button	
4	"▼" button (15 times)		"▶" button or "OK" button	
5			"▶" button or "OK" button	
6	"▼" button		"▶" button or "OK" button	Press the "♥" button to add the current station to the list of favorites for quick access in future.
7				Try to connect to the radio station.

8				Buffering the music from the radio station.
9				<p>Music playing...</p> <p>When the complete list of available radios is selected , an alphabetical research may be used by selecting on the remote control the first letter of the radio to be choosen, and the first radio starting with this letter is then displayed.</p>

## Listening to FM Radio

To listen to music or programs on local FM radio stations, select the "FM Radio" function in the main menu and then press the "OK" button to activate the FM Radio function.



The first screen of the FM Radio function displays a choice of 5 items:

- **"FM Sensitivity"**:
  - "High": Finds all available FM stations, even those with a weak signal;
  - "Low": Only searches for FM stations with strong signals.
- **"Station List"**: Retrieves the tuned radio station lists stored in the device.
- **"Favorite Stations"**: Retrieves the favorite station lists stored in the device.
- **"Update List"**: Activates the auto scan procedure to detect all available FM stations, and stores the tuned stations in the memory.
- **"Direct Access"**: Enables you to fine-tune the station frequency or switch to the previous / next FM station manually.

### Commands from the remote control:

Frequency choice mode:

◀ ▶	Forward/backward in frequency range (step of 0.05Mhz).
◀▶	Auto scanning to previous/next.
▶	Back to menu.
Vol -, ▼	Decrease the volume.
Vol +, ▲	Increase the volume.
♥	Add (or remove) the station (to the) from favourites.








Mode normal (station list, favourites):

⏪ ⏩	Previous/next in station list.
⏮ ▶	Back to station list.
Vol -, ▼	Decrease the volume.
Vol +, ▲	Increase the volume.
♥	Add (or remove) the station (to the) from favourites.

When using the FM Radio function for the first time, remember to plug the FM antenna plug into the FM antenna connector on the rear panel. Stretch out the antenna cable as far as you can.

Once the antenna cable is properly connected, activate the "Update List" function to scan the available FM stations. It takes few seconds to perform the scan operation. After that, you can tune into the stations.

The following screen shots illustrate the sequence used to pre-set the FM stations and tune into a radio station 98.70 MHz and listen to a program broadcast from it.

	Screen on the right	Screen shot	Next screen	Comment
1			"▶" button or "OK" button	Initial screen
2				
3	"▼" button (2 times)		"▶" button or "OK" button	
4				Pre-setting the FM station list according to the signal reception quality.
5				There are 15 stations tuned.
6	"▼" button		"▶" button or "OK" button	Press the "♥" button to add the current station to the list of favorites for quick access in future.
7				Tuned to station and music playing...



## Listening to the music in your computer


To listen to the music stored in your own computer, you need to install and activate the media server utility for the computer in which your digital music is stored. Please refer to the section describing installation of the Media Server.

Once you have installed and activated the media server, you can enjoy listening to the music via the Wi-Fi IP Radio device.

### Commands from the remote control:

⏩ ⏪	Fast forward/backward in the file (10 S step).
⏮ ⏭	Previous/Next file.
⏸ ▶	Pause / Play.
Vol -, ▼	Decrease the volume.
Vol +, ▲	Increase the volume.
♥	Add (or remove) the song from (to the) list of favourites.
↕	Shuffle ON / OFF: Random research.
↶	repeat: OFF / ALL / SINGLE.


Select the "Media Server" function in the main menu and then press the "OK" button to activate the stream from the Media Server function.



The following message will be displayed while the device is detecting all available media servers on your network. It takes a few seconds to complete.



The screen will then list all of the available media servers that you are able to select.












If no server is detected, the list will be empty.



Please check to ensure you have activated the media server on your computer. If, after that, there are still no media servers on the list, please refer to the troubleshooting chapter to identify the problem and solve it step by step.

The following screen shots illustrate the sequence used to connect to a media server and browsing to the music album "Chimene Badi" to play the songs on this album.


	Screen on the right	Screen shot	Next screen	Comment
1			"▶" button or "OK" button	Initial screen
2				
3	"▼" button (once)		"▶" button or "OK" button	
4			"▶" button or "OK" button	
5	"▼" button (6 times)		"▶" button or "OK" button	
6	"▼" button (4 times)		"▶" button or "OK" button	
7			"▶" button or "OK" button	Press the "♥" button to add the current station to the list of favorites for quick access in future.
8			Wait until end of song, or press "▶▶" for next song.	Music playing.
9				Next song playing.

Once the music starts, you can use the playback buttons, as you would with a traditional stereo or CD player.


## Listening to the Music on your USB drive

Supported audio formats are: \*.mp3, \*.wma, \*.wav.

To listen to the music on your USB drive or portable MP3 player, connect the USB drive to the USB connector on the Wi-Fi IP Radio device. Next, select the "MP3 Player" function in the main menu and press the "OK" button to activate the MP3 player function.



The first screen of the MP3 Player function shows the root folder content of the attached USB drive.



If the following "NO DEVICE" screen is displayed, there may be a problem in accessing the USB device. Unplug the USB device and then plug it in again.









To play back songs stored in the USB drive, simply browse the folder of the music album of your choice and then press "Play".

### Commands from the remote control:

⏩ ⏪	Fast forward/backward in the file (10 S step).
⏮ ⏭	Previous/Next file.
⏸ ▶	Pause / Play.
Vol -, ▼	Decrease the volume.
Vol +, ▲	Increase the volume.
♥	Add (or remove) the song from (to the) list of favourites.
⏴ ⏵	Shuffle ON / OFF: Random research.
↺	repeat: OFF / ALL / SINGLE.

The following screen shots illustrate the sequence used to listen to the music in the folder "Diamonds Love Song" in the attached USB drive.

	Screen on the right	Screen shot	Next screen	Comment
1			"▶" button or "OK" button	Initial screen

2				
3	"▼" button (2 times)		"▶" button or "OK" button	Select the music folder to browse and play back.
4	"▼" button (Once)		"▶" button or "OK" button	Select the music folder to browse and play back.
5			"▶" button or "OK" button	
6				

**Warning !** :The interface of MP3 reader must be USB2. USB1 is not guaranteed.

**Warning !** :Before disconnecting the MP3 player, go to the setup menu and choose "Remove MP3 player". Select "Yes" to confirm.

## The Playback Screen

When the music starts, the screen will display playback information. This includes the title of the song / station, the album & artist, and the music progression. There is also a status line at the bottom of the screen. This shows the current state of the wireless signal, the connection quality, the connection status, and the playback status. This information can help with troubleshooting if you encounter problems while listening to the music.


# ALARM

In addition to the music playback function, the Wi-Fi IP Radio Device also provides a simple alarm function. There are two different alarms, one to wake you up in the morning, and another used to remind you of important times of day, or dates.


## Clock

Before setting the alarm, you need to set the clock on the Wi-Fi IP Radio device.

First, select the Setup function in the Main Menu.




In the setup menu, the first item, "Clock", is used to set the date and time. Press the "OK" or "▶" button to set the clock.




There are 3 items in the clock menu. The first displays the current date and time; the second is used to set the date and time, and the third is the auto-Sync function (to automatically synchronize with the network server time). If you select the "Auto-sync" function, the device will periodically synchronize with the server to maintain the exact time. This is recommended.

There is also a battery in the device, so even when you switch the device OFF, the clock will keep ticking. This means you only need to set the clock once.

### Setting the Clock Manually




If you decide to set the clock manually, press the "OK" or the "▶" button to access the date and time screen. You can use the four directional buttons and the OK button to set the time.



- Use the "◀" and "▶" buttons to switch between the items to be altered. The selected item will flash.
- Use the "▲" and "▼" buttons to alter the value selected.
- Press the "OK" button to confirm.

## Setting the Clock Automatically



If you choose to set the clock automatically, access the "Auto-Sync (NTP)" menu, and select your time zone. The device will then alter the date and time automatically.




The following screen shows an example of the Time Zone screen.




## Alarm settings

To enable an alarm setting, you need to set the time and alarm music. The following table illustrates a typical alarm setting procedure. It sets Alarm 1 to generate an alarm (play music) at 7:00 AM, and to use the Internet radio station "4U Classical Rock" as the source of alarm music.

	Screen on the right	Screen shot	Next screen	Comment
1			"OK" button	Initial screen
2			"OK" button	
3	"▼" button (Once)		"OK" button	Enable alarm 1.
4			"OK" button	Use the 4 directional buttons to set the time;
5			"▶" button or "OK" button	Set Internet radio as alarm source.

6			"OK" button	Select the station from your Favorites.
7				Alarm information, displayed for 3~5 seconds
8				The alarm is set.

Once you have set and activated the alarm, a bell icon will be added to the clock screen.



When it is time for the alarm, the device will activate the alarm and play back the specified music. As with traditional clock alarms, the Wi-Fi IP Radio device also provides a SNOOZE function for you to stop the alarm, and request it to be activated 10 minutes later. You can press the "STOP" button to switch the alarm and music off completely.







*In rest position, there is no icon displayed to indicate that alarm is on.*

## Snooze

This function is used to stop the radio after a preprogrammed time.

This function is available from the following menus : Radio Internet, FM, media server and MP3 reader.

You are listening to a radio station (IP radio / FM) or a file (on PC /MP3 reader):

	Screen on the right	Screen shot	Next screen	Comment
1			"OK" button	Initial screen
2	"▼" button		"▶" "OK" button	
3	"▼" button		"▶" "OK" button	Countdown
4			"▶" "OK" button	

You can also press the "SNOOZE" key on the remote control repeatedly.



## MISCELLANEOUS SETUP FUNCTIONS

There are other useful setup functions to ensure optimum use of the device.



### Backlight Settings

You can adjust the backlight ON / OFF settings.



The default setting is always ON. You can set the backlight to be turned OFF when the device is idle (no keys pressed) after a specified amount of time.

You may also activate/deactivate the screen brightness by using the key  of the remote control.

### Language Choice

V-Tuner is a base recording the radio stations on Internet.

You may choose the IP radio and V-tuner languages.


Choice of main language (IP radio):



Choice of V-Tuner language:



### Equalizer Settings



You can adjust the equalization from Radio, media server and MP3 menus. Once the selected station screen, or file is selected, press **OK**.

## Reset to Factory Default Settings



When you reset the device to its factory default settings, your Internet radio and FM radio favorites settings will be stored in the device.

## Clear Favorites



**Caution!** This is not recommended.

## Check Firmware Version



## Software Update

This function will allow you to proceed the software updating by mean of an USB2 key containing the programm file.



Check the MEDION website to see whether there is any new firmware for this device to upgrade it. If any new firmware has been released, download it and follow the upgrade procedure below to upgrade the firmware on your device.

### Upgrading the Firmware on your Device:

**Step 1:** Uncompress the new F/W file (e.g. the file "20070315\_ShrekW\_R102C7.zip") and copy the uncompressed file "ShrekW.BIN" to the ROOT folder of a USB key or USB MP3 player.

Note: DO NOT rename it! Otherwise the Wi-Fi IP Radio will not be able to find the new F/W.

**Step 2:** Turn on the Wi-Fi IP Radio and then plug the USB key into the front USB port of the Wi-Fi IP Radio.

**Step 3:** Operate the Wi-Fi IP Radio to access the F/W upgrade menu ("Setup\Advanced Setup\ F/W Upgrade (thru. USB)"), then press the "OK" button to activate the F/W upgrade function.

The messages "F/W Upgrading", and "Don't Power Off!!" messages should be displayed. After few seconds, once the upgrade procedure has been completed, the device will reboot automatically.

**Step 4:** You can check whether the Wi-Fi IP Radio upgrade has been successful by checking the F/W version in the menu "Setup\Advanced Setup\Firmware Version". In this case, the version should be **R1.02C7**. If a different version number is shown, there may have been a problem during the upgrade.

Check to ensure the file "**ShrekW.bin**" in the USB key is the correct one.

# APPENDIX

## Care and Maintenance

Switch off your IP Radio. Use a smooth and dry cloth to wipe it. Do not use a rough cloth, powerful liquid cleaners, thinner painting, alcohol nor other solvents to clean it. These products can damage your IP Radio.

## Problems

Refer to the table below in case of an operational malfunction:

Problems	Remedies
The remote control does not function.	<ul style="list-style-type: none"> <li><input type="checkbox"/> Check that the batteries are introduced correctly.</li> <li><input type="checkbox"/> Check that you too are not too far from the radio (7 meters max.) and that the infra-red sensor is not blocked.</li> <li><input type="checkbox"/> Make sure that the remote control is well pointed towards the sensor.</li> </ul>
The screen is switched off.	<p>Make sure that :</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> the power adapter is properly connected to a power socket.</li> <li><input type="checkbox"/> the power connector is properly plugged into the radio.</li> </ul>
Chosen station can not be heard.	<ul style="list-style-type: none"> <li><input type="checkbox"/> To hear the station, you must confirm your selection by pressing <b>OK</b>.</li> <li><input type="checkbox"/> Make sure that your radio is not set to MUTE .</li> <li><input type="checkbox"/> Check the volume level.</li> <li><input type="checkbox"/> Check the network configuration.</li> <li><input type="checkbox"/> Check if the ear-phones are connected; they mute the speaker.</li> </ul>
No clear sound	The frequency FM is disturbed by parasites. Deploy the FM antenna jack until you get a clear signal.
Access denied to the Internet Radio.	Check the Wi-Fi router or the line.
Access denied to the radio from a personal computer as an access point (Media Server).	<p>Check that your radio is not encoded.</p> <p>In this case you need the encoding key to access.</p>
The alarm does not ring.	Check that the alarm source is configurated correctly.
Problem of the connexion to the router.	<ul style="list-style-type: none"> <li><input type="checkbox"/> No DHCP server enabled. Please check the setting of your router.</li> <li><input type="checkbox"/> Wrong WiFi encryption key is entered. Please double confirm the key and re-enter via the remote controller.</li> <li><input type="checkbox"/> Trouble in the RJ45 port or WiFi module.</li> </ul>
Not able to get IP Address.	<ul style="list-style-type: none"> <li><input type="checkbox"/> DNS no response. Please ping the IP address of the DNS to check if this is the case.</li> <li><input type="checkbox"/> DNS doesn't have the record of the vTuner server or radio station that you are trying to connect.</li> </ul>

<p>The connection between the radio and the vTuner is not OK.</p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Traffic jam for the internet access. Please try later.</li> <li><input type="checkbox"/> vTuner server is out of service or heavily loaded to reply in time.</li> <li><input type="checkbox"/> The authorization process is failed. vTuner server reject the access request.</li> <li><input type="checkbox"/> The streaming service of the radio station is unavailable or heavy loaded.</li> <li><input type="checkbox"/> The IP Radio doesn't support the service type of the radio station.</li> <li><input type="checkbox"/> There is some buffering trouble on the internet. The available bandwidth is not good enough to have the stable streams from the radio station.</li> </ul>
<p>The IP Radio is booted normally but it doesn't get an IP address.</p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> No DHCP server enabled. Please check the setting of your router.</li> <li><input type="checkbox"/> Wrong WiFi encryption key is entered. Please double confirm the key and re-enter via the remote controller.</li> <li><input type="checkbox"/> The network interface has trouble.</li> </ul>

In case of non receiving on Internet, refer to the following table.

What has been done with success	What could be the trouble?
<p>The IP Radio is booted normally. BUT <b>NO BAR</b> IN THE RADIO STATION LOGO (the logo with 5 bars between a radio and a computer).</p>	<p>The IP Radio doesn't get an IP address.</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> No DHCP server enabled. Please check the setting of your router.</li> <li><input type="checkbox"/> Wrong WiFi encryption key is entered. Please double confirm the key and re-enter via the remote controller.</li> <li><input type="checkbox"/> The network interface has trouble.</li> </ul>
<ul style="list-style-type: none"> <li><input type="checkbox"/> The network interface of the IP radio is good.</li> <li><input type="checkbox"/> The connection between IP Radio and router was OK.</li> <li><input type="checkbox"/> The IP Radio already got an IP address.</li> </ul> <p>BUT: <b>ONLY ONE BAR</b> IN THE RADIO STATION LOGO</p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Can't access the vTuner server.</li> <li><input type="checkbox"/> The DNS lookup for the IP address of the radio station failed.</li> <li><input type="checkbox"/> Can't access the router or internet.</li> </ul>
<p>Connection between IP Radio and vTuner server is OK. BUT: <b>ONLY TWO BARS</b> IN THE RADIO STATION LOGO</p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Can't access the radio station.</li> <li><input type="checkbox"/> The radio station rejected the connection request.</li> </ul>
<p>Connection between IP Radio and radio station is OK. BUT: <b>ONLY THREE BARS</b> IN THE RADIO STATION LOGO</p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> The streaming service of the radio station is unavailable or heavily loaded.</li> <li><input type="checkbox"/> The IP Radio doesn't support the service type of the radio station.</li> </ul>
<p>The connection between IP radio and the radio station was OK. BUT: <b>ONLY FOUR BARS</b> IN THE RADIO STATION LOGO</p>	<p>There is some buffering trouble on the internet. The available bandwidth is not good enough to have the stable streams from the radio station.</p>

# TECHNICAL DATA

## DC adapter

Input voltage: 100 V-240 V ~ 50-60 Hz 0,4 A

Output: 5 V  3 A, , 15 W

## Remote Control

Batteries: 2 x 1,5 V - R03/LR03 „AAA“

## Device

Power consumption: 11 W

Standby power consumption: 6 W

CPU: AMRISC 10020

Memory: 1 MB Flash, 2 MB SD-RAM

Speakers: 4 W

## Connections

DC IN: 5 V DC, 3 A

Ethernet Port RJ 45

WiFi antenna: 2dBi, external

FM antenna: 3,5 mm socket

LINE OUT: AV cinch sockets, stereo

Head phone: 3,5 mm socket, stereo

USB connection: 2.0

## Readable audio formats:

\*.mp3, \*.wma, \*.wav

**Subject to technical changes!**

# DISPOSAL

## Packaging



Your device is wrapped in packaging to protect it from damage during transport. Packaging is a raw material and can be re-used or added to the recycling system.

## Appliance



At the end of its life, the device must not be disposed of in household rubbish. Seek the advice of your local authority on correct, environmentally-friendly disposal. Dispose of the unit and the batteries separately.

## Batteries



Do not put used batteries in the household rubbish. Batteries should be deposited at a collection point for used batteries.

# RESTRICTED WARRANTY

## I. General Conditions of Warranty

---

### 1. General

This warranty covers defects relating to workmanship and manufacture in MEDION products. The period during which this warranty is valid and during which claims against the warranty can be made to MEDION must be in accordance with the following terms in order to be considered eligible:

- Is effective from the date of purchase or receipt of the MEDION product from an authorised seller of MEDION products; and
- expires at the end of the warranty period specified on the warranty card provided with the product.

For the warranty to be valid, you must:

- provide suitable evidence of purchase, a copy of the original purchase receipt from an authorised seller of MEDION products is preferred; or
- register your product within 28 days of purchase either online at [www.MEDION.co.uk](http://www.MEDION.co.uk) or by completing and returning the pre-paid registration card included with the product.

Please keep the original purchase receipt and the warranty card in a safe place. MEDION and its authorised sellers reserve the right to refuse a repair under warranty or a warranty confirmation if a proof of purchase [or registration of purchase] cannot be established, or has not been, submitted.

When it is necessary to return your product for repair please ensure that your product is suitably packed for transportation.

Provided that your product is still within warranty (please check the duration of the warranty period as described above) and is eligible for repair or replacement under the terms of the warranty, to return your product, please telephone MEDION on the service hotline number. You will be sent a pre-paid transportation box suitable for returning your product to MEDION. PLEASE MAKE SURE THAT YOU HAVE A BACKUP COPY OF ALL DATA ON THE PRODUCT BEFORE RETURNING THE PRODUCT TO MEDION. MEDION shall bear the costs of postage and packaging for returning the product and the transportation risk. However, if following examination of the defective product in question, MEDION, in its reasonable opinion, considers that the defect has been caused by:

- your operating and/or using the product other than as instructed in the accompanying documentation;
- damage caused in transit as a result of your negligence in packaging of the product; and/or
- otherwise than in accordance with the terms of this warranty;

This warranty shall be void and you may be required by MEDION to reimburse MEDION for the reasonable costs of postage and packaging before MEDION will return the product to you. If so and you would still like MEDION to repair or replace the product, MEDION may do so but you will be charged MEDION's standard rates for repair and replacement for this service.

Before returning the product, please contact MEDION via the service hotline or via the internet ([www.MEDION.co.uk](http://www.MEDION.co.uk)). You will receive a reference number (RMA No.) on the warranty card. Please mark the outside of your package to ensure that this reference number is clearly visible. Please submit a letter containing as much detailed information as possible and, a full description of the defect or fault.

This should include:

- a description of the fault;
- when it occurred, how long it has been evident and how frequently it occurs ;
- any errors message(s) displayed when using the product;

- a description of the circumstance(s) and conditions in which the fault occurs; and
- whether it is an intermittent or persistent fault;

This will greatly assist MEDION in identifying the defect, when submitted together with the defective product.

Unless otherwise instructed by a MEDION representative in all cases, the product must be returned complete with all parts which were included with the original product. Incomplete contents of the returned package may lead to a delay in the repair or replacement. MEDION does not accept any liability for any additionally submitted material(s) which were not supplied with the original MEDION product.

This warranty does not affect your statutory rights in any way and is subject to the applicable legal statutes of the country where the product was sold to you by an authorised MEDION seller.

## 2.Scope

Subject to any exclusions set out within this warranty, where there is a defect in your MEDION product covered by this warranty, MEDION will repair or replace the MEDION product. The decision whether to repair or replace the product will be made solely at the discretion of MEDION. MEDION may, in its own discretion, replace the product returned for repair under warranty with a replacement product that is either identical or, in the event that such product(s) are no longer available, a product of equal or superior specification and quality.

No warranty is given for batteries or rechargeable batteries or for consumable materials subject to wear and tear, i.e. for parts which have to be replaced periodically during the normal use of the product, such as video-projector lamp.

Non critical failures that fall within industry specified tolerances e.g. noise, LCD pixels are not covered by this warranty. Please consult the appropriate section in your user or instruction manual for this product for exact specifications and tolerances.

To the extent which is permitted under law, MEDION will accept no liability for burnt-in images on plasma or LCD products as a result of normal wear and tear during the operation of the product. Please refer to your user or instruction manual for this product for detailed operating instructions for your plasma or LCD product.

The warranty does not cover errors relating to the playback of data media in an incompatible format or created with unsuitable software.

If it is found during repair or assessment that the defect concerned is not covered under warranty, MEDION reserves the right to invoice you for all reasonable costs incurred by MEDION. These costs will be in relation to the return of the product, including reasonable administration costs, plus reasonable costs for materials used and labour provided when repairing or replacing the product. This is subject to MEDION providing you with an estimate for carrying out such work prior to costs being incurred and that you have accepted the estimate.

You are entitled to seek independent advice or consultation relating to your product or any of MEDION's findings. MEDION will not be liable for any costs incurred to you when doing so.

## 3.Exclusion from warranty

To the extent permitted by law, this warranty shall be void in the event that defects or loss caused by:

- a. failure and damage resulting from the operation of the product in an environment other than that recommended in the accompanying user or instruction manual (e.g. in direct sunlight or in a damp room);
- b. accidental damage;
- c. use other than in accordance with the accompanying user or instruction manual;
- d. modifications, conversions, expansions, maintenance and/or repairs made to the MEDION product by unauthorised repairers or use of unauthorised third party parts;
- e. negligence;
- f. virus attack or software errors; or



g. improper transportation or packaging during return of the product.

This warranty will also be considered void if labels or serial numbers of the product or of a component of the product are modified or made illegible.

To the extent permitted by law, MEDION shall; only be responsible for losses which are a reasonably foreseeable consequence of the relevant defect in the product; MEDION will not be responsible for any costs incurred in relation to software configuration; economic loss; loss of opportunity; loss of income; or loss of data or software arising out of its repair or replacement of a MEDION product under this warranty

#### 4. Service Hotline

Before returning the product to MEDION you must contact us using the service hotline or via the internet ([www.MEDION.co.uk](http://www.MEDION.co.uk)). You will receive further instructions for making your claim under warranty when you call.

The service hotline is available on 362 days in the year, including Sundays and bank holidays but excluding Christmas day, New Years Day and Easter day. The service hotline is subject to [national rate] telephone call charges. These charges are subject to change. The price of your call will be stated at the beginning of the call.

## II. Special warranty conditions for MEDION PC, notebook, pocket PC (PDA) and navigation devices (PNA)

---

The following terms apply to MEDION PC, notebook, desktop, pocket PC and laptop products and optional items included with such products. If one of these items has a fault, you also have a warranty claim for its repair or replacement, from MEDION. The warranty covers the costs of materials and labour for repairing or replacing the defective MEDION product or the optional item in question.

Hardware connected to your product that was not produced or marketed by MEDION can invalidate the warranty if MEDION can reasonably demonstrate that damage to the MEDION product or of the optional item included with the delivery was caused by such hardware. You are entitled to seek independent advice or consultation relating to your product or any of MEDION's findings. MEDION will not be liable for any costs incurred to you when doing so.

This warranty is restricted in relation to any pre-installed operating system as well as to application programme software that is included with the MEDION product in question. This warranty is restricted as follows:

For pre-installed operating system as well as to application programme software included in the MEDION product, MEDION only guarantees the data media (e.g. the diskettes and CD-ROMs) upon which this software is delivered and warrants that such data media shall be free from material and processing defects for a period of 90 days from the date of purchase of the MEDION product from an authorised seller of MEDION. MEDION will replace defective data media free of charge.

Any claims in respect of defective pre-installed operating system as well as to application programme software are hereby expressly excluded and you should contact the relevant licensor or copyright owner of the defective software in question. MEDION does not guarantee that any software supplied with MEDION products will function without interruption, will be free from errors or that it will fulfil your requirements. MEDION does not guarantee the 100% accuracy of the maps provided with the Navigation device.

It may be necessary to delete all data in the product in order to repair the MEDION product. PLEASE MAKE SURE THAT YOU HAVE A BACKUP COPY OF ALL DATA ON THE PRODUCT BEFORE RETURNING THE PRODUCT TO MEDION. To the extent permitted by law, MEDION excludes all liability for loss of data and MEDION recommends in all cases that you back up all data on your MEDION product before returning the product to MEDION.

### **III. Special warranty conditions for repair on site or replacement on site**

---

If a claim for repair or replacement on site is included within the terms of the warranty card provided with the product, the special warranty conditions for repair or replacement of your MEDION product on site apply.

The following provisions must be made by you for carrying out repairs or replacements on site:

- MEDION or its authorised personnel must have unrestricted, safe and immediate access to the products.
- Telecommunication facilities required by MEDION or its authorised personnel for proper execution of your order, for testing and diagnostic purposes and for remedying faults are provided by you at your own expense.
- You are responsible yourself for restoring the application software after the repair services have been carried out by MEDION or its authorised personnel.
- You must take all other necessary steps to enable MEDION or its authorised personnel to carry out your order properly.
- You are responsible yourself for connecting and configuring any existing external peripheral products after MEDION or its authorised personnel have carried out their repairs.
- The free cancellation period for repairs or replacements on site is 24 hours, thereafter our reasonable costs resulting from late or missing cancellation shall be invoiced at your expense.

**D**

MTC - MEDION Technologie Center  
 D - 45467 Mülheim / Ruhr  
 Hotline: 01805 - 668 466  
 Fax: 01805 - 654 654   
 (0,14 Euro/Minute innerhalb des deutschen Festnetzes)  
[www.medion.de/service](http://www.medion.de/service)

**BE**

MEDION Service Center  
 John F. Kennedylaan 16a  
 NL - 5981 XC Panningen  
 Hotline 022006198  
 Fax 022006199  
[www.medion.com/nl](http://www.medion.com/nl)

**CH**

MEDION Service Center  
 Rütistraße 28  
 CH - 8952 Schlieren  
 Hotline 0848 - 33 33 32  
[service-switzerland@medion.com](mailto:service-switzerland@medion.com)

**AT**

MEDION Service Center  
 Franz-Fritsch-Str. 11  
 AT - 4600 Wels  
 Hotline: 0810 - 001048  
 Fax: 07242 - 93967592  
[www.medion.de/service](http://www.medion.de/service)

**E**

MEDION Service Center Visonic S.A.  
 Alejandro Sanchez 95-97  
 E - 28019 Madrid  
 Hotline 90251448  
 Fax 914604772  
[hotline@visonic.es](mailto:hotline@visonic.es)

**F**

MEDION France  
 ZAC de la Bertraie, Route de Sablé  
 F - 72270 Villaines sous Malicorne  
 Indigo no. 0825 81 1000  
[pc-support-fr@medion.com](mailto:pc-support-fr@medion.com)

**I**

MEDION Service Center  
 Service on site S.P.A.  
 Via Kennedy 21  
 I - 20023 Cerro Maggiore (MI)  
 Hotline: 199 309077  
[service-italy@medion.com](mailto:service-italy@medion.com)

**UK**

MEDION Electronics Ltd.  
 120 Faraday Park, Faraday Road, Dorcan  
 UK - Swindon SN3 5JF, Wilts.  
 Hotline 0870 7270370  
 Fax 01793 715716  
[www.medion.co.uk](http://www.medion.co.uk)

**NL**

MEDION Service Center  
 Antwoordnummer 4015  
 NL - 5980 ZX Panningen  
 Hotline: 0900 - 633 4660  
 Fax 0900 - 654 6540  
[www.medion.com/nl](http://www.medion.com/nl)

**DK**

Medion Service Center  
 Meterbuen 6-12, Bygning 8  
 DK- 2740 Skovlunde  
 Hot-Line: 70212024  
 Fax: 70212029  
[hotline@compare-support.dk](mailto:hotline@compare-support.dk)

**MEDION**<sup>®</sup>  
[www.medion.com](http://www.medion.com)