

Hands-free Kit

What your 1 year warranty means

Great care has gone into manufacturing this product and it should therefore provide you with years of good service when used correctly. In the event of product failure within its intended use over the course of the first year after the date of purchase, we will rectify the problem as quickly as possible once it has been brought to our attention. In the unlikely event of such an occurrence, or if you require any information about the product please contact us via our after sales support services, details of which can be found in this manual and on the product itself.

Copyright © 2008

All rights reserved.

Medion® makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Medion® shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Medion® assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Medion®.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Medion®.

The information in this document is subject to change without notice.

Foreword

These operating instructions help you to use the MD 85722 hands-free device (referred to as "device") as intended, safely and for your benefit.

These operating instructions are for anyone who

- uses,
- cleans or
- disposes of this device.

Each of those persons should have read, noted and understood the total content of these operating instructions.

These operating instructions constitute part of the product. Always keep these operating instructions close to the device. Include the operating instructions with the device if you sell it or pass it on in any way.

Pre-requirements for using the functions provided

- mobile phone with Bluetooth – Bluetooth Standard 1.0 or higher
- mobile phone with voice-enabled dialling.

Notes on this Manual

Various parts of the operating instructions have fixed organisational features. These parts are made up of:

Lists (•)

Steps (▶)

Text shown in the display (“display”)



These instructions contain additional information, such as special hints for using the device economically.

Contents

Hands-free device	1	Avoiding electric shock.....	9
What your 1 year warranty means	1	Avoiding material damage	10
Foreword	3	Avoiding environmental damage	10
Pre-requirements		Organisational	
for using the functions provided.....	3	features of the safety instructions	11
Organisational features Fehler! Textmarke nicht definiert.		Device Description	12
Contents	5	Scope of supply.....	12
Safety instructions	7	Equipment and functions.....	13
Proper use	7	General view of device	14
Basic safety information	8	Charging.....	16
Avoiding risk of accident.....	8	Charging the	
Avoid risk of explosion.....	8	device in a 230V socket.....	16
Avoid risk of suffocation.....	8	Charging the device in-car.....	17
Risk of fire	8	Attaching the device to the sun visor...	20
		Choosing the display alignment	21
		Operating the device	21
		Switching on/off	22

Adjusting the volume.....	22
Accepting calls.....	22
Rejecting calls	22
Switching to "mute"	23
Ending calls	23
Accepting a second call.....	23
Dialling a number via voice dialling	24
Selecting a number from the memory	25
Call forwarding	25
Disconnecting the mobile phone and the device.....	26
Settings	27
Troubleshooting.....	32
Repairs.....	36
Cleaning	36
Recycling and Disposal	37
Technical Data	38

Safety instructions

Read through the safety instructions carefully before you start using the device. Take note of all warnings and follow all instructions on the device and in these operating instructions.

Proper use

You can use this device with a mobile phone to talk hands-free on a wireless basis.

The device can also be used as an additional display and remote control for your mobile.

The device is to be used for this purpose only. It must only be used as described in these operating instructions.

Any use other than that covered by the statutory regulations is considered improper use and can result in personal and material damage.

Any other use or modification of the device is considered improper use and can result in material damage.

The manufacturer is not liable for damage caused by improper use or incorrect operation. The device is not intended for commercial use.

Basic safety information

Avoiding risk of accident

Observe the statutory regulations, especially when making telephone calls while driving a vehicle.

- Use the hands-free function.
- Do not pick up the phone once the engine is running and you are in traffic.

Installation of the device in the car should not adversely affect the following:

- Driver safety, range of vision and freedom of movement,
- Passenger safety (also in the event of an accident),
- Vehicle safety devices, e.g. airbag, safety belts and hazard lights switch.

Avoid risk of explosion

- You must not operate the device in an environment where there is a risk of explosion.

Avoid risk of suffocation

- Do not allow children to play with the plastic packaging film.

Risk of fire

- Avoid additional heat, e.g. from direct sunlight, heaters and other devices.

Avoiding electric shock

- Only use the device in dry environments.
 - Make sure that no liquids can get into the device at any time.
 - Check the device and all components for visible damage. You must only use the device when it is in perfect condition.
 - When charging the device at the mains, use only a professionally installed socket (240V~ 50Hz).
 - The plug must be freely accessible so that you can disconnect the device from the mains quickly and easily in the event of emergency.
 - Remove the mains plug from the socket if a fault occurs or if you are not charging the device. Grasp only the plug to remove.
- Avoid exposing the power pack to drops of water or spray. Do not place water-filled objects water (e.g. vases) on, above or adjacent to the power pack.
 - Do not kink or pinch the mains cable.
 - Do not touch the mains cable with wet hands.
 - If the mains cable is damaged, you must replace the power pack with another one of the same power rating before reusing the power pack.
 - The device is also intended for use with 12V. Use only the 12V power supply (cigarette lighter) to charge the device in the car.
 - The charger cable must be freely accessible, so that you can remove it quickly and easily in an emergency.

- Remove the plug from the charge in the event of faults. Grasp only the plug.
- Do not kink or pinch the charger cable.
- Do not touch the charger cable with wet hands.
- If the charger cable is damaged, you must exchange it for a similar one before using again.
- Never allow children to use the device unsupervised or to play with it. Store the device out of reach of children.
- Allow only qualified specialists to perform maintenance. Otherwise, you put yourself and others at risk.

Avoiding material damage

- You must be able to reach the control elements in the car after the device has been installed.

Avoiding environmental damage

- Dispose of the device and its accessories in accordance with statutory regulations.

Organisational features of the safety instructions

These operating instructions contain the following categories of safety instructions and general instructions:



WARNING!


Instructions containing the word “WARNING” draw attention to a dangerous situation which can possibly result in death or serious injury.

ATTENTION!

Instructions containing the word “Attention” warn of a situation which can result in material or environmental damage.

Device Description

Scope of supply




- 1 Hands-free device
- 2 In-vehicle charger for operation on the 12V power supply (cigarette lighter socket)
- 3 Power pack (jack connector may vary)
- 4 Metal clip for fitting to the sun visor

Equipment and functions

- DSP (Digital Signal Processor)
- Caller's own number illuminated brightly on dark display
- "Speak numbers" in five languages:
 - English
 - Spanish
 - French
 - German
 - Italian
- Display adjustable between five languages
- Switching microphone to "mute"
- Voice dialling
- possibility of transferring calls to mobile phone
- Battery charging display
- Battery charge-level display
- 20-number memory
 - memory for up to 10 calls received
 - memory for up to 10 missed calls
- Detection of up to four mobile phones
- Up to eight hours calling time
- Up to 100 hours standby call time

General view of device



- 1** LCD display
- 2** Connect device and mobile phone
Disconnect device from mobile phone
During a call: switch to “mute”
- 3** During a call: transfer a call
- 4** Microphone
- 5** “Accept call” button
- 6** “Hand up” button
- 7** Volume button
+ button: Increase volume
- button: reduce button
- 8** Battery charging display
- 9** Loudspeaker
- 10** On/Off button
- 11** Battery charger

Charging



DANGER!

Carelessness can lead to accidents!

- ▶ Do not perform the following actions when you are in traffic.

The device is charged via the car charging cable in the car or with the power pack, also supplied, which is plugged into a mains socket (240 V~ 50 Hz).

Charging the device in a 240V socket

- Insert the small power pack plug into the device charger
- Insert the large mains plug in a 240 V socket.

The charge indicator lights up red.

The charge indicator lights up green when the device is fully charged.

Charging the device in-car

- ▶ Insert the small plug from the car charger cable into the device charger.




DANGER!

Starting the car can result in power spikes in the 12V power supply.

- ▶ Wait until the engine is running before connecting the charger cable to the 12V power supply.
- ▶ Insert the large plug for the car charger cable in the 12V power supply (cigarette lighter).

The charge indicator lights up red.

The charge indicator lights up green when the device is fully charged.



To save your car battery, do not charge the device for long periods with the car engine switched off.

Connecting the device with a mobile phone (pairing)



DANGER!

Carelessness can lead to accidents!

- ▶ Do not pair the devices while the car is moving.

You will have to set up a Bluetooth connection between the device and your mobile phone to use the device for hands-free, wireless calls. This is referred to as “pairing” the two devices.

If you have successfully completed pairing, the mobile and the device automatically recognize one another as soon as you start the search for a Bluetooth device.

- ▶ Please refer to the operating instructions for your mobile phone on how to make a Bluetooth connection to your mobile.
- ▶ Start the search for a Bluetooth device from your mobile, as described in the operating instructions for the mobile.
- ▶ To switch on the device, slide the POWER button, located on the top of the device, to the right.

The mobile phone searches for a Bluetooth device.

- ▶ When the search is finished, select “MD 85722” from the list on the mobile’s display.

- ▶ To connect your mobile to the device, enter the password "1234".

The device will recognize your mobile phone after the password has been entered.

The word "Paired" will appear on your mobile phone display.

If your mobile does not have a hands-free function, the "headset profile" appears on the display. In this case, accept the call using the "hang-up" button.

The name of the paired mobile phone will also be displayed.



If the connection attempt fails, start again from the beginning. If the connection attempt has been successful, the device is ready for operation.

The mobile phone will, in future, be recognised by the device.

- ▶ To do this, initiate the Bluetooth device search function on your mobile phone.
- ▶ Switch the device on.

Both devices will be connected automatically.

Attaching the device to the sun visor



DANGER!


Carelessness can lead to accidents!

- ▶ Do not fit the kit while the car is moving.

You can attach the device to your car's sun visor using the metal clip supplied.

- ▶ Slide the metal clip onto the edge of your car's sun visor.
- ▶ Place the device in the centre of the metal clip (1.).

The magnets on the rear hold the device firm on the metal clip.



- ▶ Rotate the microphone so that the person you are talking to can hear you clearly (2.).
- ▶ If necessary, select the display alignment.

Choosing the display alignment

- ▶ Press button L and hold it down for about two seconds.

You will see the "Settings" menu on the display.

- ▶ Press the "+" button five times in quick succession.

You will see "Adjust displays" on the display.

- ▶ Press the "+" key once.

You will see "Normal display" on the display.

- ▶ Press the "+" key once.

You will see "upside-down display" on the display.

- ▶ To see "normal display" on the display, press the "+" button again.

- ▶ Press the "accept call" button to adjust a setting.

If you have chosen "upside-down display", the script in the display is now upside-down.

Operating the device



DANGER!

Observe the statutory regulations, especially when making telephone calls while driving a vehicle.

- ▶ Use the hands-free function
- ▶ Do not use the mobile phone when in traffic.

Switching on/off

- ▶ To switch on the device, slide the POWER button, located on the top of the device, to the right.

The device is switched on.

- ▶ To switch the device off, slide the POWER button, located on the top of the device, to the left.

The device is switched off.

Adjusting the volume

- ▶ To increase the volume, press the "+" button.
- ▶ To reduce the volume, press the "-" button.

Accepting calls

- ▶ Press the "accept call" button on the device
- or

- ▶ press the "accept call" button on the mobile phone.

Rejecting calls

If necessary, you can reject a call instead of accepting it.

- ▶ Press the "hang-up" button on the device

or

- ▶ press the "hang-up" button on the mobile phone.

Switching to "mute"

- ▶ Press the "L" button to switch the microphone to mute during a conversation.

On the display you will see "Mute On". The microphone is off.

- ▶ To switch the microphone on again, press the "L" button again.

On the display you will see "Mute Off". The microphone is switched on.



The microphone will be switched on again automatically after a call has ended.

Ending calls

- ▶ To end a call, press the "hang-up" button on the device

or

- ▶ press the "hang-up" button on the mobile phone.

Accepting a second call

A second person tries to call while one call is in progress.

- ▶ To accept the second call, press the "accept call" button.
- ▶ The first call is put on "hold".
- ▶ To talk to the first call participant again, press the "accept call" button.

The second call is put on "hold".

- ▶ To end the call with the first call participant, press the "hang-up" button.

Now you can talk to the second caller.

- ▶ To end the call with the second call participant, press the "hang-up" button.

Dialling a number manually



DANGER!

Not paying attention while driving can cause an accident!

- ▶ When the vehicle is moving use only the hands-free function to dial the number.

Dialling a number via voice dialling



You can only use the voice dialling function if your mobile supports it.

Before dialling by voice, you must save the desired number in the mobile.

- ▶ Press the C button for two seconds.
- ▶ You will hear a beep.
- ▶ Then speak the name of the required number.

The required number will be dialled.

Selecting a number from the memory

The last 10 accepted calls and the last 10 missed calls are saved in the memory.

- ▶ Press the "accept call" button for two seconds.

You will see "calls received" on the display.

- ▶ Press the "+" or "-" button to select the desired number.
- ▶ Press the "accept call" button to select the required number.
- ▶ Press the "accept call" button to make a call.

Call forwarding

If you are in the middle of a call when getting into the car you will be required to forward the call to the device.

- ▶ Press the C button to transfer calls from your mobile phone to the device.

You will have to forward the call to your mobile phone if you are carrying on a telephone conversation when getting out of the car.

- ▶ Press the C button to transfer calls from the device to your mobile phone.



If you are using a Nokia mobile press the "L" button to transfer calls from your mobile phone to the device.

Disconnecting the mobile phone and the device

There are four methods for disconnecting the mobile phone and the device:

- ▶ Briefly press “L” button,
- ▶ Switch off the device,
- ▶ Switch off the mobile,
- ▶ Move the mobile phone 10 metres from the device.

Settings



DANGER!

Not paying attention while driving can cause an accident!

- ▶ Do not make changes to any of the settings while the vehicle is moving.



You can only change settings in the menu if the Bluetooth connection to the mobile is established.

- ▶ You can only change settings in the menu if the Bluetooth connection to the mobile is established.

- ▶ Press button L and hold it down for about two seconds.

You will see the "Settings" menu on the display.

- ▶ To navigate downwards, press the "+" button.
- ▶ To navigate upwards, press the "-" button.
- ▶ Press the "accept call" button to change the settings.
- ▶ To quit the menu, press the "hang-up" button.

If you have not made any settings for about 20 seconds, the "Settings" menu disappears.

The following table contains a summary of the device menu and the possible settings.

Function	Selection	Make setting
Contrast	Settg. (setting) contrast	<ul style="list-style-type: none"> ▶ To increase the contrast, adjust the bar with the + button. ▶ To reduce the contrast, adjust the bar with the – button. ▶ Press the “accept call” button to change the setting.
Playback volume	Spkr. (speaker) Vol. (volume)	<ul style="list-style-type: none"> ▶ To increase the volume, adjust the bar with the + button. ▶ To reduce the volume, adjust the bar with the - button. ▶ Press the "accept call" button to change the settings.

Function	Selection		Make Setting
Keypad tone on or off	Settg. keypad tone	Off	<ul style="list-style-type: none"> ▶ To hear the key tone, press the + button once. ▶ To switch the key tone to "mute" press the + button twice. ▶ Press the "accept call" button to change the settings.
		On	
Delete list of accepted / missed / all calls	Settg. Rec. Del.	Rec. Del. receive	<ul style="list-style-type: none"> ▶ To delete the accepted calls, press the + key once. ▶ To delete the missed calls, press the + key twice. ▶ To delete all calls, press the + key three times. ▶ Press the "accept call" button to change the settings.
		Rec. Del. mssd. call	
		All	

Function	Selection		Make Setting
"Normal" or "upside-down" display	Display setting	normal display	<ul style="list-style-type: none"> ▶ To see the normal display, press the + button once. ▶ To see the upside-down display, press the + button twice. ▶ To make a setting, press the "accept call" button.
		Upside-down display	
Delete recognition for all mobiles	Delete pairs	Del. pair HFP yes	<ul style="list-style-type: none"> ▶ To delete recognition for all mobile phones, press the "accept call" button. ▶ If you have deleted the connection to the mobile phone by mistake, you must carry out pairing again. ▶ Proceed as described in the section from page 3 onwards.

Function	Selection		Make Setting
"Speak numbers" on or off	Tone	On	<ul style="list-style-type: none"> ▶ To switch on "Speak numbers", press the + button once. ▶ To switch off "Speak numbers", press the + button twice ▶ Press the "accept call" button to make changes to the settings.
		Off	
Languages	Language	Deutsch, Italiano, English, Español, Français	<ul style="list-style-type: none"> ▶ Select the desired language using the + or - button. ▶ Press the "accept call" to make changes to a setting.

Troubleshooting

Nature of problem	Cause	Remedy
The device and the mobile do not recognise one another.	The device is not charged.	▶ Charge the device battery as described on page 16.
	Pairing was not successful.	▶ Pair the devices. ▶ Follow the instructions from page 21 onwards.
	The search on the mobile for a Bluetooth device has not been enabled.	▶ Enable the search for a Bluetooth device from your mobile, as described in the section from page 21 onwards.
	The mobile phone is faulty.	▶ Have the mobile phone tested by the manufacturer.

Nature of problem	Cause	Remedy
The device and the mobile do not recognise one another.	Since the last instance of use, at least four other phones have been registered.	<ul style="list-style-type: none"> ▶ Pair the devices. ▶ Proceed as described in the section from page 21.
The mobile has recognised additional Bluetooth devices.	There are several Bluetooth devices within the operating range.	<ul style="list-style-type: none"> ▶ Select "MD 85722" from the list on your mobile, as described in the section from page 21.
Poor reception	You are on the edge of the range of reception.	<ul style="list-style-type: none"> ▶ Change the position of your mobile phone.
		<ul style="list-style-type: none"> ▶ Follow the recommendations of your mobile manufacturer.

Nature of problem	Cause	Remedy
Voice dialling does not work.	The mobile is not enabled for voice dialling.	▶ Use a mobile that supports voice dialling.
	The number is not saved in the mobile phone's voice dialling directory.	▶ Save the number in the mobile phone's voice dialling directory.
	The device is not connected to the mobile.	<ul style="list-style-type: none"> ▶ Ensure the device is connected to the mobile. ▶ Proceed as described in the section from page 21.
The person you are calling can only hear you faintly.	The microphone is not pointing correctly towards you.	▶ Align the microphone as described in the section from page 20.

Nature of problem	Cause	Remedy
The person you are calling cannot hear you clearly.	The microphone is in the airstream of the car sunroof, window or ventilation.	<ul style="list-style-type: none">▶ Move the clip which attaches holds your kit to the sun visor.▶ Alter the airstreams in the car.
You hear the person you are calling too faintly.	The volume is set too low.	<ul style="list-style-type: none">▶ To increase the volume press the + button.

Repairs

Please contact the MEDION Australia Helpdesk on 1300 884 987 if you have any problems with your device. ONLY have repairs completed by our authorised service centre.

Contact you the MEDION Australia Helpdesk on 1300 884 987 when...

- liquid has got into the device
- the device does not operate properly
- the device is dropped or the housing is damaged.

Cleaning

- Clean the device with a moist cloth.
- Do not use any type of solvents, caustic or gaseous cleaning agents.

Recycling and Disposal



Use the collection points provided for disposal of electrical appliances and dispose of electrical appliances for which you have no further use.

By doing this you are helping to prevent the potential effects of incorrect disposal on the environment and on human health.

You are also making a contribution to recycling and to other forms of reuse of used electrical appliances and electronic devices.

You can obtain information on where to dispose of appliances from your local authority or council.

Technical Data

Standard	Bluetooth V1.2, Class II
Frequency	2.4 GHz
Battery type	rechargeable Lithium-Polymer Battery
Operating distance	approx. 5 m
Call time	approx. 8 hours
Standby	approx. 100 hours
Weight	approx. 140 g
Dimensions in mm (H x W x D)	approx. 55 x 160 x 23

